



WI FLOOR MEMBRANE KIT

INSTALLATION GUIDE



Simplicity
WETROOMS

WI FLOOR MEMBRANE INSTALLATION GUIDE

I. USES

WI Floor Membrane is a self-adhesive waterproofing and decoupling membrane designed for use prior to the application of ceramic or porcelain tiles and natural stone onto timber and solid floors in wetrooms and other critical areas.

WI Floor Membrane is comprised of a 1mm thick Compound of an elastomeric modified Butyl rubber (Grey Colour) and the backing is a non-woven PP fleece 85g/m² (White Colour).

2. ELEMENTS

5m² WI Floor Membrane kit

5m x 1m roll of membrane
10m Reinforcing Tape
500ml Primer
290ml Jointing Compound
4 Pre-formed Internal Corners

10m² WI Floor Membrane kit

10m x 1m roll of membrane
15m Reinforcing Tape
1L Primer
290ml Jointing Compound
4 Pre-formed Internal Corners



3. APPLICATION - A STEP BY STEP GUIDE

Please ensure that you read these instructions in full before commencing work. The complete system should be applied strictly in accordance with these instructions.

Surfaces must be smooth, solid and sound. Ensure all surfaces are clean, dry and free from dust, grease, oil etc. and free from all contaminants. Oily or greasy surfaces should be cleaned with a suitable proprietary cleaner and thoroughly rinsed and allowed to dry.


Ensure that both the primer and membrane are compatible with any existing coatings. If in doubt, please refer to the manufacturer.

Care should be taken to ensure the ambient room temperature is at least 5°C. Conditioning of the membrane in a warm area prior to use will enhance its adhesion properties during the application process.

WI FLOOR MEMBRANE INSTALLATION GUIDE

1 PRIME FLOOR

Use a brush or roller to apply the primer along wall-floor junctions and across the floor area to be waterproofed.




NB - TAKE CARE NOT TO APPLY PRIMER TO THE ABS PLASTIC DRAINAGE COMPONENT

2 PRE-FORMED INTERNAL CORNER

Apply a small bead of the Jointing Compound to the back of the Pre-formed Corner and place into position, pressing firmly into place.

Before applying the reinforcing tape (see next section) ensure that it is cut square in order for it to butt up neatly to the tape stop (see diagram to the right).


NOTE: The reinforcing tape should not be applied over the raised section of the preformed internal corner. **NB Do not apply primer to the pre-formed internal corner.**



3 TAPE WALL-FLOOR JUNCTIONS

Apply Reinforcing Tape to all wall-floor junctions as follows:

- Cut tape to required length
- Fold in half along the pre-scored line ensuring that the backing paper is visible on both sides. Offer up to the wall, with the fold towards the wall.
- Remove upper half of backing paper and stick to the wall.
- Lift up lower lip, remove backing paper and stick to the floor.
- Repeat this process until all wall-floor junctions have been taped.
- Apply a minimum 200mm strip of Reinforcing Tape (within the shower area) vertically to all the corner wall/wall junctions (full height when using with W3 Wall Membrane).




WI FLOOR MEMBRANE INSTALLATION GUIDE

4 TAPE MEMBRANE JUNCTIONS


Ensure Reinforcing Tape is applied to the floor where membrane sections will meet.

- Measure width of the membrane (diagram shows membrane width of 1m)
- Cut Reinforcing Tape to the required length for the area being waterproofed (width of room, if whole room is to be waterproofed).
- Position Reinforcing Tape so that when overlaid, each section of membrane will overlap tape by 62mm (see 1. in diagram).
- Remove backing paper and stick tape down, ensuring tape adheres into corners at the side of the shower area (see 2. diagram).
- Repeat floor taping until all membrane junctions have been covered.



5 TAPE EXTERNAL CORNERS


Use reinforcing tape to make up two sections to cover an external corner according to the steps in the diagram.



6 LAY FLOOR MEMBRANE

Lay membrane onto wetroom floor as follows:

- Cut membrane to required length.
- Wipe the surface of the Drainage Component and all Reinforcing Tape, with the alcohol wipe supplied in the kit BEFORE applying the membrane
- Score and remove 150mm of backing paper from the end of membrane roll and turn over so backing faces floor.
- Position sticky edge of membrane into the corner and smooth out any air pockets.
- Roll up membrane into the corner.
- Slowly un-roll membrane away from the wall, removing the backing paper as you go, sticking it to the floor and smoothing out any potential air bubbles.
- Repeat this process until the membrane covers the required area.




WI FLOOR MEMBRANE INSTALLATION GUIDE

7 LAY FLOOR MEMBRANE

To reveal drain use a sharp knife to carefully cut around the **INNER EDGE** of the Drainage Component, then remove the membrane from inner section of the Drainage Component.

For the wall surfaces within the shower area we recommend the application of **W3 Wall Membrane**. For more details see separate instruction guide.




8 APPLY JOINTING COMPOUND

When all of the floor area has been covered with membrane, the floor is then ready for application of the Jointing Compound.

- Using an applicator gun, apply Jointing Compound to:
 - All butt joints (see diagram)
 - Pipe penetrations
 - Perimeter of drain (see diagram)
 - All wall to wall and wall to floor junctions

The waterproofing process is now complete and the floor is ready for tiling / floor covering.



WI FLOOR MEMBRANE INSTALLATION GUIDE

4. TECHNICAL DATA

WI Floor Membrane is a unique, pre-formed flexible self-adhesive waterproofing and decoupling membrane.

It is ideal for use on substrates such as timber, masonry, concrete, plasterboards, gypsum and existing ceramic or natural stone. Once applied, WI Floor Membrane is ready to tile immediately.

WI Floor Membrane is cold applied, consisting of a 1mm thick Butyl waterproof layer, incorporating a non-woven PP fleece.

It has been developed for use prior to the fixing of ceramic or porcelain tiles and natural stone and is applied using a flexible rapid-set tile adhesive, which is key to the fabric. As the adhesive dries it forms a strong permanent bond to the membrane.

WI Floor Membrane and ancillary products should be stored in the original cartons, kept upright, protected from frost, and out of direct sunlight ie below 35°C. Cartons should not be over stacked.



Membrane Thickness	1mm
Reinforcing Tape Thickness	1mm
Tensile Strength (ASTM D882)	115N/50mm - (Cross Direction)
Anti-fracture & Decoupling (Tinius Olsen)	10mm
Elongation at break (ASTM D882)	120% - (Cross Direction)
Peel Adhesion at 180° angle (ASTM 3330)	≥ 11N /10mm

Compatible with electric underfloor heating up to 150w per m²

WI FLOOR MEMBRANE INSTALLATION GUIDE

5. PIPE PENETRATIONS / ENTRIES

1. Pipe penetrations should be examined to ensure that the membrane will be fully supported.
2. Any voids around the pipe penetrations should be filled using appropriate filler and allowed to dry.
- 3a. For small pipe penetrations (smaller than 50mm) cut a hole in the WI Reinforcing Tape to suit the pipe size, remove backing paper, then press down on the Reinforcing Tape to ensure it has fully adhered to the substrate (fig i).
- 3b. For large pipe penetrations (greater than 50mm) apply two pieces of Reinforcing Tape around the pipe, by carefully cutting the Reinforcing Tapes to suit the pipe entry size, remove backing paper, then press down on the Reinforcing Tape to ensure it has fully adhered to the substrate (fig i).
4. When applying the membrane, cut holes in the membrane approximately 5mm - 10mm larger than the penetration (to assist with applying membrane over the pipe penetration), as per 3a or 3b. Apply the membrane over the Reinforcing Tape.
5. Apply WI Jointing Compound onto the Reinforcing Tape joints, around the pipe penetrations and on to the membrane to all Reinforcing Tape joints (fig i).
6. Repeat the process of either 3a or 3b for pipe penetrations on the wall, then apply W3 Wall Membrane over the top of the Reinforcing Tape.



WI FLOOR MEMBRANE INSTALLATION GUIDE

6a. INSTALLING A GLASS SCREEN ONTO MEMBRANE





Concrete Floor

1. Place glass shower screen channel into position and mark the fixing points.
2. Remove the glass shower screen channel, drill the marked fixing points and apply a small amount of WI Jointing Compound directly into the hole (fig i).
3. Insert appropriate fixings and apply another small amount of WI Jointing Compound on top of the plug.
4. Apply a continuous line of WI Jointing Compound to the underside of the glass shower screen channel (fig ii).
5. Align glass shower screen channel and fix into position using appropriate fixings.
6. Apply a suitable amount of WI Jointing Compound around and on top of all fixings (fig iii).



Timber Floor

1. Place glass shower screen channel into position and mark the fixing points.
2. Apply a continuous line of WI Jointing Compound to the underside of the glass shower screen channel (fig ii).
3. Replace glass shower screen channel & fix in place using suitable fixings.
4. Apply a suitable amount of WI Jointing Compound around and on top of all fixings (fig iii).
5. Finished view of glass shower screen once installed





WI FLOOR MEMBRANE INSTALLATION GUIDE

6b. INSTALLING A GLASS SCREEN ONTO TILES




Concrete Floor

1. Place glass shower screen channel into position and mark the fixing points
2. Remove glass shower screen channel, drill the marked fixing points to the required depth and apply a small amount of WI Jointing Compound directly into the hole (fig i).
3. Insert appropriate fixings and apply another small amount of WI Jointing compound on top of the fixings.
4. Apply a continuous line of WI Jointing Compound to the underside of glass shower screen channel (fig ii)
5. Align glass shower screen channel and fix into position. using appropriate fixings.
6. Apply a suitable amount of WI Jointing Compound around and on top of all fixings (fig iii)
7. Finished view of glass shower screen once installed (fig iv).



Timber Floor

1. Place glass shower screen channel into position and mark fixing points, then remove.
2. Using the appropriate drill bit carefully drill through the thickness of the tile taking care not to pierce the membrane.
3. Apply WI Jointing Compound into the hole (fig i).
4. Apply a continuous line of WI Jointing Compound to the underside of the glass shower screen channel (fig ii).
5. Align glass shower screen channel & fix into position using appropriate fixings.
6. Apply WI Jointing Compound around and on top of all fixings (fig iii).
7. Finished view of glass shower screen once installed (fig iv).



WI FLOOR MEMBRANE INSTALLATION GUIDE

7. WETROOM WATERPROOFING SPECIFICATION

WI Floor Membrane - Entire Bathroom


WI Floor Membrane to be applied to the entire bathroom floor area.

Additional Reinforcing Tape to be applied to all wall junctions, soap niches and other such detail within the shower area.

W3 Wall Membrane to be applied to the walls within the shower area only, to a minimum height of 2000mm and overlapping the Reinforcing Tape.

All pipe penetrations to be sealed with Jointing Compound.

For steam rooms W3 Wall Membrane should be applied to all the walls.




WI Floor Membrane - Shower area + 1 Metre

WI Floor Membrane to be applied to the shower floor area, plus a minimum of 1 metre outside the shower area in all directions.

Reinforcing Tape to be applied to all wall junctions, soap niches and other such detail within the shower area.

W3 Wall Membrane to be applied to the walls within the shower area only, to a minimum height of 2000mm and overlapping the Reinforcing Tape.

All pipe penetrations to be sealed with Jointing Compound.



Please Note

Decoupling will only be effective when WI Floor Membrane is applied to the entire bathroom floor area.

WI FLOOR MEMBRANE INSTALLATION GUIDE


8. OVER BATH SPECIFICATION

WI Floor Membrane is to be applied to the floor area under the bath, plus a minimum of 1 metre outside the bath in all directions.

Reinforcing Tape is to be applied to all wall junctions, soap niches etc within the bath area and overlapping onto the Reinforcing Tape.

W3 Wall Membrane is to be applied to the walls within the bath area, to a minimum height of 2200mm and down to the floor, overlapping the Reinforcing Tape.

All pipe penetrations to be sealed with WI Jointing Compound.



Please Note

Decoupling will only be effective when WI Floor Membrane is applied to the entire bathroom floor area.

9. ANHYDRITE SCREED, LOOSE LAID SCREED & LATEX LEVELLING COMPOUNDS

- The above types of substrate may require sealing prior to priming. This will normally be required approx. 24/48hrs prior to the installation of WI Floor Membrane to ensure it is sufficiently dry.
- Fully sweep the area to be sealed to remove as much dust as possible.
- Mix Primer 5:1 ratio with clean water.
- Fully soak the area with sealer ensuring all areas are covered. (If the area hasn't been sealed 24/48hrs prior to installation, then the sealer must be left to fully soak into the substrate for approx. 15/20min's before being forced dried with the use of heaters & fans).
- When the sealed area has fully dried it can then be primed as normal using the Primer.
- It is recommended that a bond/adhesion test is carried out prior to the application of the waterproofing membrane.

